



No.	Part no.	Name
7	450504-6	F/R CHANGE LEVER TW100D/DF030D
17	629853-4	DC MOTOR DF030D/DF330D
5	631813-4	LED CIRCUIT TD090D/DF330D
10	643830-2	TERMINAL TW100D/TD090D/DF330D
8	650699-7	SWITCH C3HW-3A-LF1M DF090D/DF0
8	650699-7	SWITCH C3HW-3A-LF1M DF090D/DF0
8	650699-7	SWITCH C3HW-3A-LF1M DF090D/DF0
3	866201-8	NAME PLATE DF330D
18	911003-8	*PAN HD SCREW M3X6 10PK
2	187409-4	HOUSING SET
19	187409-4	HOUSING SET
15	766007-3	KEYLESS CHUCK 10 DF330D
16	125539-3	GEAR ASSY DF330D
1	126233-0	SPEED CHANGE LEVER ASSY HP330D
1	126233-0	SPEED CHANGE LEVER ASSY HP330D
2	187358-5	HOUSING SET HP330D
19	187358-5	HOUSING SET HP330D
2	187359-3	HOUSING SET DF030D/330D
2	187359-3	HOUSING SET DF030D/330D
19	187359-3	HOUSING SET DF030D/330D
19	187359-3	HOUSING SET DF030D/330D
6	232239-9	LEAF SPRING DF030D/DF330D
14	251451-2	*SLOT HD SETSCREW M5X22 5PK
4	266130-9	*TAPPING SCREW BIND 3X 16 10PK
9	345998-7	SET PLATE TW100D/UM16